

WaterWheeler ASL

Electric Pedal Boat



Manufactured by:

KL
INDUSTRIES

1790 Sun Dolphin Drive
Muskegon, Michigan 49444

phone 231-733-2725

fax 231-739-4502

email klsales@klindustries.com

website www.klindustries.com

Table of Contents

Important Information to Conserve	P. 1
How to Locate Your Serial Number	P. 1
Sea-Doo Boat Features	P. 3
Security Measures	P. 4
Material	P. 5
Boat Set-up	P. 5
Rudder/Steering Assembly	P. 5
Seat Back Installation	P. 5
Seat Back Adjustment	P. 6
Canopy Assembly	P. 6
Manufacturers Statement of Origin	P. 6
Applying Decals.....	P. 6
Product Safety Information	P. 7
Before Leaving Shore	P. 7
Care and Maintenance	P. 8
Storage	P. 9
Frequently Asked Questions	P. 9
Consumers Warranty	P. 10

Dear Customer,

Congratulations on the recent purchase of your new WATER WHEELER ASL ELECTRIC pedal boat manufactured by KL Industries! You have purchased a boat from one of the nations leading manufacturers of small boats. Your boat represents years of commitment to product design, excellence in engineering and quality in manufacturing. With proper care and maintenance your pedal boat should last for many years to come. Please call our helpful and knowledgeable Customer Support Department if you have any questions.

IMPORTANT INFORMATION TO CONSERVE

Keep your owners manual for future reference. In order to provide you with efficient and accurate service, please have the following information available:

Model and Serial Number _____

Date and Place of Purchase _____

To order parts and accessories visit our website at www.klindustries.com or contact us at 800-733-2727.

HOW TO LOCATE YOUR SERIAL NUMBER

The serial number is located on the outside of the deck in the back right hand corner. The number starts with JOK and is 12 digits long (photo #1).

WARRANTY

Please call us at 231-733-2725 if you have questions or a problem with your boat. Do not return the boat to the retailer.

KL Industries, Inc. warrants to the original owner of any KL Industries boat. Any part of the boat that is defective in material or workmanship will be repaired, without charge, at the purchasers' local dealer or at KL Industries. For personal use, this warranty shall apply for a period of five years on the deck and hull and two years on parts from the date of retail sale. Any warranties from suppliers of component parts supersede KL Industries' warranty. This warranty covers use under normal conditions and does not cover damage caused by accidents, alteration, or misuse. Freight to and from a local dealer or manufacturing plant is at the owners' expense. Warranty is not valid unless registration form is returned within 30 days of retail purchase.

Register online at: www.klindustries.com

Warranty



Integrated Minn Kota® electric motor for effortless cruising (battery not included)



Choose the option of exercise through pedal power or the ease of motorization with the flick of a switch



Battery compartment (battery not included)

SPECIFICATIONS

Length	91"
Width	64"
Height	24"
Weight	130 lbs.
Capacity	800 lbs.

Water Wheeler




© KL Industries

Water Wheeler ASL Electric

ADJUSTABLE SUN
LOUNGER
ELECTRIC
POWERED
PEDAL
BOAT



INCLUDES
CANOPY



Available Accessories:

- Seat Cushions • Misting Cover
- Salt Water Drive System



Available Color



Blue

SECURITY MEASURES

WARNING

Read the following information before using your paddle boat. Failure to follow the warning precautions below may lead to serious injury including the possibility of death.

- ⚠ **Never exceed the maximum weight capacity.**
- ⚠ **Never exceed your ability:** Assess your physical capability as to how far and how long you can pedal and swim.
- ⚠ **Make sure your drain plugs are secure.** The drain plugs are located in the back of the boat on the outside of the hull.
- ⚠ **Always familiarize yourself with the body of the water where you will be boating:** Learn what hour boating is permitted, whether there are any known hazardous conditions, and where you can get help quickly in case of emergency or accident.
- ⚠ **Always abide by Coast Guard regulations and State and local laws, regulations, ordinances and rules concerning boating and boating safety:** Check with Coast Guard and local authorities concerning proper handling and the proper equipment to be carried on board, such as lights and sound-producing devices.
- ⚠ **Never use or consume alcohol, drugs or any other substance that may affect your coordination, judgment or ability to safely operate the boat.**
- ⚠ **Sound device:** The Coast Guard requires boaters to have a means of signaling other boats of their presence. You should always keep a device such as a whistle in the boat at all times. If possible, attach the sound device to your Personal Flotation Device.
- ⚠ **Never stand up in the boat:** Standing in the boat may cause it to capsize. If the boat should capsize, please note that, in most cases it is far more dangerous to attempt to swim to shore than to stay with the boat.
- ⚠ **Slippery when wet:** The hull material may be slippery when wet. Always wear slip-resistant shoes.
- ⚠ **Hypothermia:** Boating accidents in cold water are very dangerous. Hypothermia (the loss of body heat due to immersion in cold waters) can be deadly. Survival time can be as short as 15 minutes in 35 degree F (2 degree C) water. Dress appropriately for weather conditions, wearing a wet or dry suit if necessary.
- ⚠ **Never allow minors to use this boat without adult supervision:** Never allow any minor to use this boat unless accompanied by an adult.
- ⚠ **Never use this boat alone:** It is best to have someone with you in case of emergency or accident. Also, always tell someone your boating plans, including where you are going, how long you will be gone and how many people you'll be with.
- ⚠ **Never use this boat in severe weather conditions:** Although stable, large waves could cause the boat to overturn.
- ⚠ **Never use this boat in rapids or fast moving currents:** This boat is designed for leisure. The boat could be damaged and (or) the occupants could be severely injured should they attempt to utilize it in any other way.
- ⚠ **Never use this boat after sunset:** This boat is not equipped with horns or lighting equipment, required to ensure the safety of its occupants.
- ⚠ **Every passenger should always wear a Coast Guard approved personal flotation device (PFD) when using this boat:** Before going boating, read the PFD manufacturer's information pamphlet regarding the PFD and thoroughly familiarize yourself with how the PFD is to be worn.

Follow all safety precautions listed in the pre-launch and launching procedures. When launching, be sure the motor is in the “up” position. To put it in the up position, lift the handle up until the spring is straight. The spring is stiff enough to hold the motor in this position. Move the boat to the water as recommended previously.

Problem: Motor Won't Run

Probable Cause

Corrective Action

Problem: Motor runs but will not move boat.

Probable Cause

Corrective Action

Problem: Motor Runs Slow

Probable Cause

Corrective Action

Problem: Prop strikes hull

Probable Cause

Corrective Action

Problem: Motor runs backwards.

Probable Cause

Corrective Action

Problem: Motor only operates on one or two speeds.

Probable Cause

Corrective Action

Problem: Motor starts but soon stops.

Probable Cause

Corrective Action